

DANCOVER[®]

.com

Manual
for
Inflatable Tent
TentZing

Inflatable Tent Instruction Guide

Hello, thanks for purchasing our Inflatable Tent!

Here is a golden rule to help you get years of use out of your tent:

ALWAYS, WITHOUT FAIL, STORE YOUR TENT BONE DRY OR
YOU WILL RUN THE RISK OF GETTING A MOULDY TENT!

Content List

Inflatable Tent

THE CONTENTS SHOULD BE AS FOLLOWS:

1 x Carrybag

1 x Canvas Tent

1 x Electric inflator pump

12 x Pin Pegs

8 x Guy Ropes & Sliders

1 x Repair Patch

1. Unpack your tent and lay it out with the groundsheet floor facing. Make sure the ground is flat and free of any sharp objects. Find the door and rotate to face desired direction.



2. Keeping the tent fabric on top of the base, stretch the groundsheet. Locate the elastic rings and use the smaller pegs to fix your base to the ground.



3. Locate the valves to inflate the tent.



4. Insert the pump nozzle into the valve and start pumping. 2/3 into the inflation process you will need to manually push the tent roof upwards to help air flow through the tubes evenly.



5. The first time you use the tent you will have to attach the guy ropes to the canvas loops at the bottom end of the roof. After this they can be left attached in place for your next trip.



6. Take the larger ridged pegs and peg out the tent ropes. Tension of the rope should be equal and not over tight. Once you have completed all guy ropes you can adjust to suit.



Enjoy your inflatable tent and remember please only store it bone dry.
Many thanks and feel free to call us if you get stuck.

Contact information

Austria



Belgium



Croatia



Denmark



Estonia



Finland



France



Germany



Ireland



Italy



Latvia



Lithuania



Nederland



Norway



Poland



Portugal



Spain



Sweden



Switzerland



UK

