



Surfflag is available in three sizes.



Complete package includes:

- 1 pc carrybag
- 1 pc Screwbase
- 1 pc Rotator
- 1 pc Pole (4 parts)
- 1 pc Flag



1 Screw the base into the ground.



2 Connect the rotator.



3 Connect the 4 parts of the pole.



4 Pull the flag on to the pole.



5 Make sure the tip of the pole is pushed all the way to the end of the flag lining.




6 Attached the hook, located at the bottom of the flag, to the bracket on the pole.



7 As easy as "one two three!"

The tip must be pushed to the end.



When switching flags make sure the knob is still mounted to the tip of the pole. Otherwise there is a risk it will break through the lining.



Important!
If the tip of the pole is not pushed all the way to the end of the lining, there is a risk it will break through the lining.

Contact information

Head office:
Dancover A/S
Nordre Strandvej 119 G
3150 Hellebæk
Denmark

For more information please visit:
www.dancovershop.com

Local contact information

- Denmark: denmark@dancover.com
- UK: uk@dancover.com
- Germany: germany@dancover.com
- France: france@dancover.com
- Sweden: [sverige@dancover.com](mailto: sverige@dancover.com)
- Finland: suomi@dancover.com
- Poland: polska@dancover.com
- Luxembourg: luxembourg@dancover.com
- Spain: espana@dancover.com
- Italy: italia@dancover.com
- Switzerland: schweiz@dancover.com
- Austria: austria@dancover.com
- Norway: norge@dancover.com
- Nederland: nederland@dancover.com
- Ireland: ireland@dancover.com
- Belgium: belgique@dancover.com