

DANCOVER[®]



Manual
for
Bubble Machine

BUBBLE MACHINE

PC130000 Instruction Manual

SAFETY INSTRUCTIONS

1. When using electrical appliances, basic safety precautions should always be followed.
2. Do not immerse the appliance in water or any other liquids (apart from the bubble making liquid that should only be put in the front compartment).
3. Close supervision is required when using this appliance near children.
4. Never leave the appliance within reach of children.
5. Repairs to electrical appliances should only be performed by a qualified electrician. Improper repairs may place the user at serious risk.
6. This appliance is intended for household use only and should not be used for industrial purposes.
7. Do not use this appliance for anything other than its intended use.

BATTERY SAFETY

Always:

- Ensure the battery compartments are secure.
- Only use the batteries recommended.
- Ensure correct fit of batteries, observing the plus and minus marks on both the battery and the compartment.
- Replace a full set of batteries in their packaging and keep away from metal objects that may cause a short circuit.
- Remove dead batteries from equipment.
- Remove batteries from appliances that will not be used again for a long time.
- Supervise children with batteries at all times.
- Remember to keep small button cell and batteries away from small children as they can be easily swallowed.
- Seek immediate medical attention if batteries are swallowed.

Never:

- Mix old and new batteries.
- Mix different types of batteries.
- Dispose of batteries in a fire.
- Attempt to recharge ordinary batteries.

INSTRUCTIONS FOR USE

1. This is an electrical appliance, not a toy. Keep out of reach of children and pets.
2. Place the machine on a solid, flat, stable surface.

3. Avoid direct sunshine and sources of heat.
4. Be aware that when the bubbles break, it will form a wet slippery surface. Please take care and wipe clean with a dampened cloth.
5. Pour approximately 1 pint of the bubble liquid (not included) into the front compartment of the machine where the wheel spins round.
6. Always unplug the adaptor (not included) if being used before filling.
7. It is advisable not to run this unit for more than one hour at a time to prolong the lifetime of the motor.

CLEANING & MAINTENANCE

- Clean the appliance with a soft, damp, lint free cloth.

REPLACING THE BATTERIES

- If your machine stops working after a while, the batteries may require replacing.
- Switch Off the On/Off switch and remove the only screw from the top of the product.
- Remove the top cover and remove the old batteries and replace with a new 1.5V LR 14 'C' type battery. Replace the top cover and replace the fixing screw.

Technical data

a) General

Input voltage/current.....	3 V/DC, 800 mA
Power consumption.....	2.4 W
Battery operation	2 x 1.5 V type C batteries, LR 14 (batteries are not supplied)
Soap capacity	250 ml (soap bubble liquid is not supplied)
Soap consumption.....	approx. 250 ml in 40 min. (approx. 375 ml/h)
Coverage area of the soap bubbles	approx. 1 x 1 m
Protection class	III
Operating / storage conditions.....	0 to +40 °C, 0 – 90 % RH
Dimensions (L x W x H).....	225 x 180 x 150 mm
Weight (without power adapter).....	600 g

b) Power adapter

Input power/current of the power adapter..	100 – 240 V/AC, 50/60 Hz, 0.2 A max.
Output power/current.....	3 V/DC, 800 mA
Protection class	II

DANCOVER[®]

.com

Contact information

Head office:

Dancover A/S
Nordre Strandvej 119 G
3150 Hellebæk
Denmark

For more information
please visit:

www.dancovershop.com

National contact

Denmark: 70 26 76 20
denmark@dancover.com

UK: 020 8099 7570
uk@dancover.com

Germany: 041 0266 7040
germany@dancover.com

France: 0975 181 800
france@dancover.com

Sweden: 040 233 262
sverige@dancover.com

Finland: 0 931 581 720
suomi@dancover.com

Poland: 22 300 8602
polska@dancover.com

Luxembourg: +49 041 0266 7040
luxembourg@dancover.com

Portugal: 308 800 899
portugal@dancover.com

Spain: 911 436 828
espana@dancover.com

Italy: 02 479 21 198
italia@dancover.com

Switzerland: 0840 000125
schweiz@dancover.com

Austria: 0662 626935
austria@dancover.com

Norway: 231 00 690
norge@dancover.com

Nederland: 0 858 880 524
nederland@dancover.com

Ireland: 0 151 33 003
ireland@dancover.com

Belgium: 0 28 08 08 09
belgique@dancover.com