

**DANCOVER<sup>®</sup>**



Manual  
for  
Work Tent  
5m Series

# DANCOVER<sup>®</sup>

.com

## Safety Advice

### Attention

In some countries approval is needed to set up a marquee/tent larger than 75 m<sup>2</sup>. It is your responsibility to comply with local rules and regulations and to ensure that the marquee/tent is assembled correctly.

In case of bad weather conditions, it is your responsibility to ensure the marquee/tent is safely secured and that the marquee/tent does not cause damage to others.

Do not use open fire, welding equipment or other sources which can ignite, inside or close to the tent.

The marquee/tent must be safely secured. We recommend you secure your marquee/tent with straps and pegs as soon as it is assembled.

Make sure to check if the marquee/tent is covered by your home contents insurance.

Marquees/tents must be evacuated under extreme weather conditions.

In the event of snow always remove snow from the roof of the marquee/tent regularly to prevent snow from building on the roof as heavy snow can cause the marquee/tent to collapse.

In the event of rain there is a risk of rain puddles building up on top of the roof of the marquee/tent. Heavy rain puddles can cause the roof to collapse. It is your responsibility to ensure rain puddles do not build up. As a precaution, make sure the roof of the marquee/tent is stretched out properly and adequately over the side frames of the marquee/tent and remove rain water regularly.

Do not unpack or repack your marquee/tent in freezing temperatures. In case of temperatures below zero always unpack and repack your marquee/tent indoors to avoid the risk of cracking parts.

The marquee/tent must be totally dry before you repack and store it to avoid mildew.

Note: Marquees are intended for events and other arrangements and are as such only meant for short term temporary assembly and the following disassembly. Dancover warranty applies only to the normal use of the Product, normal wear and tear excepted, in accordance with written use instructions or manual. The warranty does not apply to damage caused by accident, abuse, misuse, or modification of the Product.

### Warranty Information

Please visit [dancovershop.com](http://dancovershop.com) for information on warranty.

*Please always check our website for the latest safety advice and manual.*















## Warning

---















1. In order to avoid being rusted by air, oil is covered on the surface of the pipes, before set up the tent, please remove the oil carefully first to keep the cover clean.
2. Take note that the tent needs to be handled carefully to avoid damage.
3. Do not force the frame as they may be damaged in the process.
4. Tents are meant as temporary shelter and must be evacuated under extreme weather conditions.

Please select a suitable site for the tent to avoid the damage to underground sprinkler systems, water, gas or electrical lines.
















# 5m Storage tent manual

Part No.			5x6m	5x8m	5x10m
1	Middle leg 1880mm Ø50		4	6	8
2	Frame pole 1880mm Ø38		11	16	21
3-1	Frame pole 1880mm Ø38		2	2	2
3-2	Frame pole 1880mm Ø38		2	2	2
4	Frame pole 1880mm Ø50		8	10	12
5	Frame pole Ø50		8	10	12
6	Diagonal support 1174mm Ø25		4	4	4
7	Roof support 1652mm Ø25		4	5	6
8	Corner leg 1880mm Ø50		4	4	4
9	Female doorbar Ø38		2	2	2
10	Male doorbar Ø38		2	2	2
11	Pillar Ø50		4	4	4
12	Pillar Ø50		4	4	4
13	Ceiling rail Ø25		2	2	2


# 5m Storage tent manual

Part No.			5x6m	5x8m	5x10m
14	Ceiling rail Ø25		2	2	2
15	Groundbar pipe Ø38		4	4	4
16	3-way connector for corner 54-42mm		2	2	2
17	3-way connector for corner 54-42mm		2	2	2
18	3-way connector for sidewall 54-42mm		8	10	12
19	4-way connector 110° 54-42mm		4	6	8
20	3-way connector 110° 54-42mm		4	4	4
21	3-way connector 140° 54-42mm		2	2	2
22	4-way connector 140° 54-42mm		2	3	4
23	Strengthen bar for roof cover		6	8	10
24	Bracket Ø50		12	14	16
25	Groundbracket Ø38		6	8	10
26	Peg 400mm		12	16	20
27	Spiral peg		4	4	4


# 5m Storage tent manual

Part No.			5x6m	5x8m	5x10m
28	Long peg		12	14	16
29	Small peg		32	36	40
30	Bungeeball long		44	44	44
31	Rope		4	4	4
32	Screw M6x30mm		10	12	14
33	Screw M6x45mm		5	5	5
35	M6 wingnut		15	17	19
37	Screw M8x50mm		50	60	70
38	Screw M8x60mm		54	64	74
39	M8 nut		104	124	144
40	Spanner		1	1	1
41	Steel tension bar		12	16	20
42	Turnbuckle		6	8	10
43	Tie down		4	4	4
44	Steel clip		20	24	28
45	Roof		1	1	1
46	Endwall		2	2	2


**I**  
 Select a flat surface at ground for the tent, unpack the carton and check all the parts including tubes, tent and accessories... etc. are present and the same as the list.  
 Assemble the framework of rooftop by joining the portion (19, 20, 21, 22) together with poles (2, 3-1, 3-2, 4, 5) NO. 3 is on four corners for diagonal pipe.



**II**  
 To ensure the screw fixed to every pole tightly. And then use the turnbuckle and steel tension bar to tighten the top structure.




**III**  
 Attach one end of supported pole (1, 8) to the joints.




# IV

Attach the other supported poles (1, 8) to the joints, built-up the framework.



# V


You facilitate the assembly and dismantling by pulling the roof with ropes on tent frame. Use the steel clips to fasten the cover to the frame. Each section we offer bracket and nail to fasten the frame to ground.





## VI

Spread the wall panel and door panel, attach to framework by using the bungee cords clasping the frame to grommets that is construct over the wall panel and door panel to ensure stability. Also use the short pegs to fix the doors to the ground.



# DANCOVER<sup>®</sup>



## Contact information

### Head office:

Dancover A/S  
Nordre Strandvej 119 G  
3150 Hellebæk  
Denmark

For more information  
please visit:  
[www.dancovershop.com](http://www.dancovershop.com)

## National contact

Denmark: 70 26 76 20  
[denmark@dancover.com](mailto:denmark@dancover.com)

UK: 020 8099 7570  
[uk@dancover.com](mailto:uk@dancover.com)

Germany: 041 0266 7040  
[germany@dancover.com](mailto:germany@dancover.com)

France: 0975 181 800  
[france@dancover.com](mailto:france@dancover.com)

Sweden: 040 233 262  
[sverige@dancover.com](mailto:sverige@dancover.com)

Finland: 0 931 581 720  
[suomi@dancover.com](mailto:suomi@dancover.com)

Poland: 22 300 8602  
[polska@dancover.com](mailto:polska@dancover.com)

Luxembourg: +49 041 0266 7040  
[luxembourg@dancover.com](mailto:luxembourg@dancover.com)

Portugal: 308 800 899  
[portugal@dancover.com](mailto:portugal@dancover.com)

Spain: 911 436 828  
[espana@dancover.com](mailto:espana@dancover.com)

Italy: 02 479 21 198  
[italia@dancover.com](mailto:italia@dancover.com)

Switzerland: 0840 000125  
[schweiz@dancover.com](mailto:schweiz@dancover.com)

Austria: 0662 626935  
[austria@dancover.com](mailto:austria@dancover.com)

Norway: 231 00 690  
[norge@dancover.com](mailto:norge@dancover.com)

Nederland: 0 858 880 524  
[nederland@dancover.com](mailto:nederland@dancover.com)

Ireland: 0 151 33 003  
[ireland@dancover.com](mailto:ireland@dancover.com)

Belgium: 0 28 08 08 09  
[belgique@dancover.com](mailto:belgique@dancover.com)